

# Bedienungsanleitung / Manual : LED-Nixie6-Sound-Cronios3 1.20

---

English please see below.

Bei Neustart und gleichzeitig **gedrückter Taste während der Versionsanzeige** (halten bis Beep hörbar), erfolgt eine Zurücksetzung auf (**Standard**) Werte. (Bitte ausführen falls Funktionen nicht funktionieren).

Bei Neustart und gleichzeitig **gedrückter Microtaste während der Versionsanzeige** (halten bis Beep hörbar), erfolgt die Umschaltung zwischen **DE/EN** Sprache.

Drehregler stellt die Farben ein, kurzer Druck wechselt zwischen Uhrzeit und Datum. Die Farbeinstellung wird bei Druck gespeichert. Datum springt nach ca. 3 Sekunden automatisch auf Uhrzeit zurück. Farben: 0-9 = feste Werte, 10= weiß, 11=Glühlampe(**Standard**), 12-14=Multi-Farbe.

Langer Druck auf die Taste **während Zeitanzeige** startet das Einstellungsmenü (weiß).

Langer Druck auf die Taste **während Datumanzeige** startet das Systemmenü (blau).

Drehen = **Funktion**, kurzer Druck = ausführen, langer Druck = ende (mit Speichern).

Automatischer Abbruch nach ca. 4 Sek. Nichtaktivität. (ohne speichern).

Kurzer Druck auf den **Microknopf** sagt den Wochentag und die Zeit an.

Langer Druck auf den **Microknopf** sagt die Temperatur an (-59 bis +59 °C).

Bei aktivem Nachtmodus: Langer Druck auf den **Microknopf** = Nachtmodus manuell aus.

*Das Menu wird gesprochen.*

*Alle Einstellungen bleiben bei Stromausfall erhalten (EEPROM).*

*Bei angeschlossenem Terminal (PC) weitere Ausgabe von Werten.*

*Alarm ist priorisiert bei Timer / Stoppuhr.*

*Versionsanzeige bei Uhrenstart.*

*Softwareversionscheck bei Systemstart.*

## Einstellungs Menü: (weiß)

### 0: Beeper ein/aus (1)

0 = aus , 1 = ein

### 1:12 / 24 Stunden Anzeige (24)

12 / 24

### 2: Uhrzeit einstellen (24 Stunden Anzeige)

kurzer Druck wechselt zwischen Stunden, Minuten, Sekunden (**gelb**)

langer Druck setzt die eingestellte Zeit

### 3: Datums Format (0)

0 = DDMMYY

1 = MMDDYY

2 = YYMMDD

### 4: Datum einstellen

kurzer Druck wechselt zwischen Tag, Monat, Jahr

langer Druck setzt das eingestellte Datum

### 5: Alarm ein/aus (0)

0 = aus , 1 = ein

## 6: Alarmzeit einstellen (24 Stunden Anzeige) (12:00)

kurzer Druck wechselt zwischen Stunden, Minuten  
langer Druck setzt die eingestellte Alarmzeit

## 7: Datum Auto Anzeige ein/aus (0)

0 = aus , 1 = ein

## 8: Timer (max. 23:59:00)

kurzer Druck wechselt zwischen Stunden, Minuten  
langer Druck setzt die eingestellte Timerzeit.  
Danach kurzer Druck Start / Stopp  
Langer Druck bei Stopp = Ende

## 9: Stoppuhr (max. 23:59:59)

kurzer Druck = Start / Stopp  
Langer Druck bei Stopp = Ende

## Systemmenü: (blau)

### 0: Helligkeit einstellen (12)

1...15 = Helligkeit feste Werte  
0 = Automatische Helligkeit über Sensor

### 1: Minimum Helligkeit bei Auto Helligkeit (2)

0...15 = Minimum Helligkeit für Sensor (ist nicht fester Helligkeit-Wert)

### 2: Partymodus ein/aus (0)

0 = aus , 1 = ein

### 3: Random (Spielautomat) ein/aus (0)

0 = aus , 1 = ein

### 4: Sekundenflip ein/aus (0) (Wenn ein, Überblendemodus keine Wirkung)

0 = aus , 1 = ein

### 5: Überblende Modus einstellen (3)

1...5 = Überblende Dauer  
0 = Überblende aus

### 6: Stunden und Viertelstunden Ansage (1)

0 = aus , 1 = ein

### 7: DF-Player Lautstärke (8)

0...30 = Lautstärke

### 8: Nachtmodus einstellen (Dauer)(00:00)

Während Nachtmodus ist Partymodus, Spielautomat und Stunde / Viertelstunde Sound deaktiviert.  
Wenn **Anfang** und **Ende** gleich sind, ist der Nachtmodus deaktiviert.  
kurzer Druck wechselt zwischen: **Anfang** Stunden, **Anfang** Minuten (gelb)  
langer Druck setzt die eingestellte Zeit, danach:  
kurzer Druck wechselt zwischen: **Ende** Stunden, **Ende** Minuten (grün)  
langer Druck setzt die eingestellte Zeit.

# Operations manual: LED-Nixie6-Sound-Cronios3 1.20

---

On startup, the display shows the software version for approx. 2 seconds.

To **reset to factory defaults**: as soon as the software version number displays, **press and hold** the spinner button until unit beeps.

To **toggle between DE/ENG speech**: as soon as the software version number displays, **press and hold** the microknob until unit beeps.

Turn the knob to adjust the display color. (0-9 solid color, 10 white, 11 **incandescent**, 12-14 multi color). Short press knob to switch between Clock and Date display, Changing display also ensures color setting is saved when restarting. Date display automatically returns to clock display after approx. 3 seconds.

Long press spinner button **during time display** to enter settings menu (white).

Long press spinner button **during date display** to enter the system menu (blue).

Turn knob to choose an option, short press to select, long press to exit (with saving changes).

After 4 seconds inactivity, the unit returns to display mode (without saving changes).

Short press **microknob** to say DAW / Time.

Long press **microknob** to say Temp. Range -59...59 °C.

If Night mode is on, long press **microknob** to manual set it to off.

*Menu is spoken. Softwareversioncheck at startup.*

*All settings remain in case of power failure (EEPROM).*

*The alarm is prioritized over the timer and stopwatch.*

*If connected to a PC running LED-Basic, the current EEPROM values are displayed on the screen at program start for debugging purposes.*

## Settings menu (white):

### Setting 0: beeper on / off (default 1)

0 = off, 1 = on

### Setting 1: 12 / 24 hour clock display (default 24)

12 = 12 hour clock

24 = 24 hour clock

### Setting 2: Set the time (24 hour clock)

Short press changes between hours, minutes, seconds (yellow)

long press saves the time

### Setting 3: Date format display (default 0)

0 = DDMMYY

1 = MMDDYY

2 = YYMMDD

### Setting 4: Set the date

Short press changes between days, months, years

Long press saves the date

### Setting 5: Alarm on / off (default 0)

0 = off, 1 = on

### Setting 6: Set alarm time (24 hour clock)( default 12:00)

Short press changes between hours and minutes

Long press saves the alarm time

### Setting 7: Auto date display on / off (default 0)

0 = off, 1 = on

### Setting 8: Timer (max 23:59:00)

Short press changes between hours and minutes

Long press sets timer duration

Then short press to start / stop timer

To exit, long press whilst timer stopped

### Setting 9: Stopwatch (max 23:59:59)

Short press to start / stop stopwatch

To exit, long press whilst stopwatch stopped

## System menu (blue):

### System 0: adjust brightness (default 12)

1...15 = brightness level,

0 = automatic brightness (set using sensor)

### System 1: Minimum brightness for auto brightness (default 2)

0...15 = minimum brightness for sensor (no brightness level)

### System 2: Party Mode On / Off (default 0)

0 = off, 1 = on

### System 3: Slot machine mode on / off (default 0)

0 = off, 1 = on

### System 4: Second flipping mode on / off (default 0) (when on, Fade mode not working)

0 = off, 1 = on

### System 5: Fade mode (default 3)

1...5 = fade duration

0 = off

### System 6: Hour / Quarter Sound on / off (default 1)

0 = off, 1 = on

### System 7: DF-Player Volume (default 8)

0 ... 30

### System 8: Set the Night mode duration (default 00:00)

if **begin** and **end** are the same, Night mode is disabled.

During Night mode on, Partymode, Slot machine and Hour / Quarter Sound are disabled.

Short press changes between **begin** hour, **begin** minute (yellow)

long press saves, then -->

Short press changes between **end** hour, **end** minute (green)

long press saves

*Slot machine mode: at 4, 8, 14, 18, 24... minutes past the hour, LEDs are lit at random for 10 seconds.*

*Party mode: every other minute (01, 03, 05...), one of 7 "party 'displays" at random are shown for a few seconds.*

*Second flipping mode: flipping from '9' to '0', the seconds display cycles through 9...8...7... ...0.*

*If on, Fade mode has no function!*

*When alarm is On, alarm time displays twice every ten minutes (minutes 02, 06, 12, 16, 22...) in red.*

*Fade mode: Digits are fading depending on value. NOT working when **Second flipping mode** is on!*

*Night mode: brightness on minimum at night mode duration.*

*if begin and end are the same, Night mode is disabled.*

*During Night mode on: Partymode, Slot machine and Hour / Quarter Sound are disabled.*