

Bedienungsanleitung: LED-TextNixie 2.30

Wenn nach Neustart und einer **Wartezeit** von ca. **einer Sekunde** die Taste gedrückt wird, erfolgt eine Zurücksetzung (**BEEP**) auf Standard Werte **UND** Auswahl der Sprachversion.
Drehen = Auswahl (GER / ENG), Taste = übernehmen.

Kurzer Druck auf die Taste startet das Einstellmenü. (SETUP - leicht zeitverzögert) Anzeige durch °.
Langer Druck auf die Taste beendet das Einstellmenü. (SETUP)
Drehen = Funktion F, H, Z, P, kurzer Druck = ausführen.

Alle Einstellungen bleiben bei Stromausfall erhalten (EEPROM).
Versionsanzeige bei Uhrenstart. Versionscheck bei Start.
Bei angeschlossenem Terminal (PC) weitere Ausgabe von Werten.

F = Farbe:

Drehen = Farbauswahl. (Farbe, Zufalls-Farbe, Fading).
Kurzer Druck = übernehmen. Springt bei Nichtbetätigung nach ca. 2 Sekunden ohne Speichern auf Setup zurück.

H = Helligkeit:

Drehen = Helligkeit (19 Stufen) plus Auto = A.
Kurzer Druck = übernehmen. Springt bei Nichtbetätigung nach ca. 2 Sekunden ohne Speichern auf Setup zurück.

Z = Zeit :

Drehen = Zahl, Kurzer Druck = übernehmen. Format: HH:MM. (z.B.13:56).
Springt bei Nichtbetätigung nach ca. 2 Sekunden ohne Speichern auf Setup zurück.

P = Partymodus:

Drehen = P ON / P OFF, Kurzer Druck = übernehmen.

Manual: LED-TextNixie 2.30

When the system is starting and the button is **pressed after approximately one second**, it will be reset to standard values (**beep**) **AND** selection of the language version can be done.
Turn = selection (GER/ENG), key = accept.

A short press on the button starts the setting menu. (SETUP, slightly delayed). Display by °.
Long press on the button ends the setting menu. (SETUP)
Turn = function C, B, T, P, short press = execute.

All settings are retained in case of power failure (EEPROM).
Version display at clock start. Softversion check at startup.
With connected terminal (PC) further output of values.

C = color:

Turn = color selection. Short press = Apply. Color, random color, fading.
Jumps when not in use after about 2 seconds without saving back to setup.

B = brightness:

Turn = Brightness (19 levels) plus Auto = A. Short press = Apply.

Jumps when not in use after about 2 seconds without saving back to setup.

T = time:

Turn = Number, Short press = Apply. Format: HH: MM. (Z.B.13: 56).

Jumps when not in use after about 2 seconds without saving back to setup.

P = Partymodus:

Turn = P ON / P OFF, Short press = Apply.