

# Bedienungsanleitung: LED-TextNixie 2.31

---

Nach Neustart und **sofort danach** gedrückter Taste, erfolgt eine Zurücksetzung (**BEEP**) auf **Standard** Werte **UND** Auswahl der Sprachversion.  
Drehen = Auswahl (**GER** / **ENG**), Taste = übernehmen.

Kurzer Druck auf die Taste startet das Einstellmenü. (SETUP - leicht zeitverzögert) Anzeige durch °.  
Langer Druck auf die Taste beendet das Einstellmenü. (SETUP).  
Drehen = Funktion F, H, Z, P, kurzer Druck = ausführen.

Alle Einstellungen bleiben bei Stromausfall erhalten (EEPROM).  
Versionsanzeige bei Uhrenstart. Versionscheck bei Start.  
Bei angeschlossenem Terminal (PC) weitere Ausgabe von Werten.

## SETUP:

### F = Farbe:

Drehen = Farbauswahl. (**Farbe**, Zufalls-Farbe, Fading).  
Kurzer Druck = übernehmen. Springt bei Nichtbetätigung nach ca. 2 Sekunden ohne Speichern auf Setup zurück.

### H = Helligkeit:

Drehen = Helligkeit (**19** Stufen) plus Auto = A.  
Kurzer Druck = übernehmen. Springt bei Nichtbetätigung nach ca. 2 Sekunden ohne Speichern auf Setup zurück.

### Z = Zeit :

Drehen = Zahl, Kurzer Druck = übernehmen. Format: HH:MM. (z.B.13:56).  
Springt bei Nichtbetätigung nach ca. 2 Sekunden ohne Speichern auf Setup zurück.

### P = Partymodus:

Drehen = P ON / **P OFF**, Kurzer Druck = übernehmen.

# Manual: LED-TextNixie 2.31

---

**Soon** after the system is starting and the button is **pressed** , it will be reset to **standard** values (**beep**) **AND** selection of the language version can be done.  
Turn = selection (**GER**/ENG), key = accept.

A short press on the button starts the setting menu. (SETUP, slightly delayed). Display by °.  
Long press on the button ends the setting menu. (SETUP)  
Turn = function C, B, T, P, short press = execute.

All settings are retained in case of power failure (EEPROM).  
Version display at clock start. Softversion check at startup.  
With connected terminal (PC) further output of values.

## **SETUP:**

### **C = color:**

Turn = color selection. Short press = Apply. **Color**, random color, fading.  
Jumps when not in use after about 2 seconds without saving back to setup.

### **B = brightness:**

Turn = Brightness (**19** levels) plus Auto = A. Short press = Apply.  
Jumps when not in use after about 2 seconds without saving back to setup.

### **T = time:**

Turn = Number, Short press = Apply. Format: HH: MM. (Z.B.13: 56).  
Jumps when not in use after about 2 seconds without saving back to setup.

### **P = Partymodus:**

Turn = P ON / **P OFF**, Short press = Apply.